

# 1. 패스워드 Recovery 절차

## ▶ 대상제품.

. L2 Switch : P3624FG, P3608FG

## ▶ STEP 1.

- 콘솔 연결 및 장비를 리부팅하여, 부트모드로 진입 (부팅직후, CTRL+C 입력)

## ▶ STEP 2.

- 부트모드 프롬프트에서 패스워드를 초기화/저장 실행

```
uboot> setenv -p epasswd yes
uboot> saveenv
uboot> bootflash
done
```

```
Switch running is P3624FG.....
INIT: version 2.86 booting
INIT: Entering runlevel: 3
```

## ▶ STEP 3.

- 부팅완료 및 Default Password 로 장비 접속여부 확인

```
Switch running is P3624FG...
INIT: version 2.86 booting
INIT: Entering runlevel: 3
```

Ubiquoss L2 Switch

```
Switch login: root      [Recovery가 완료되면 default password로 로그인후 필히 password를 수정 후 저장 해야함]
Password: premier
Hello.
Switch>
```

### [첨부] Config 초기화 설정 or Password 변경.

- Config 초기화 설정

```
Switch> enable
Switch# erase startup-config
```

```
Warning: start.cfg is the next booting config file
Do you want to erase it? [yes/no] yes
Next boot config file was erased from flash filesystem!!
```

- Password 변경

```
Switch> enable
Switch# configure terminal
Switch(config)# username root password [변경password입력]
Switch(config)# end
Switch# copy running-config startup-config
Overwrite 'start.cfg_bak'? [yes/no] yes
```