

1. 패스워드 Recovery 절차

▶ 대상제품.

. L2 Switch : P8624XG, P8724XG

▶ STEP 1.

- 콘솔 연결 및 장비를 리부팅하여, 부트모드로 진입 (부팅직후, CTRL+C 입력)

▶ STEP 2.

- 부트모드 프롬프트에서 패스워드를 초기화/저장 실행

```
Premier8K > setenv epasswd yes
Premier8K > saveenv
Premier8K > run bootcmd
Loading /flash/p8xg.r148 complete
Image Name: 1.4.8
Image Type: PowerPC Linux Multi-File Image (gzip compressed)
Verifying Checksum ... OK
Uncompressing Multi-File Image ... OK
~ 이 하 생 략 ~
```

▶ STEP 3.

- 부팅완료 및 Default Password 로 장비 접속여부 확인

```
UbiQuoss L3 Switch
Switch login: root
Password: frontier
switch> enable
switch#
```

[Recovery가 완료되면 default password로 로그인후 필히 password를 수정 후 저장 해야함]

[첨부] Config 초기화 설정 or Password 변경.

- Config 초기화 설정

```
Switch> enable
Switch# erase startup-config
```

```
Warning: start.cfg is the next booting config file
Do you want to erase it? [yes/no] yes
Next boot config file was erased from flash filesystem!!
```

- Password 변경

```
Switch> enable
Switch# configure terminal
Switch(config)# username root password [변경password입력]
Switch(config)# end
Switch# copy running-config startup-config
Overwrite 'start.cfg_bak'? [yes/no] yes
```